



P.O. Box 41376
Dayton, OH 45459
Ph. 937.790.6143
Fx. 937.395.3543

OUTLINE for FIRE ALARM SYSTEM WIRING

ARTICLE 760 - “Fire Protective Signaling Systems”

- General
- Non Power-Limited Fire Protective Signaling Circuits
- Power-Limited Fire Protective Signaling Circuits
- Power-Limited Fire Alarm Circuits (PLFA)
 - Writing Methods
 - PLFA Power Source Wiring Methods on the Supply Side
 - PLFA Power Source Wiring Methods on the Load Side
 - Installation of Conductors and Equipment in Cable Tray, Compartment, Enclosure, Outlet Box, Raceway, etc.
 - Listed Power-Limited Fire Alarm Circuits (PLFA) cables
- Non Power-Limited Fire Alarm Circuits (NPLFA)
 - NPLFA Wiring Methods for Multi-conductor Cables
 - Listed Non-Power-Limited Fire Alarm Circuits (NPLFA) Cables
- Conductors
- Circuit Marking Requirements

Reference:

NFPA 70 - The National Electrical Code

Hosts: Dave Craynon & Lisa Salzman

- Dave is a 42 year Sprinkler expert and holds NICET certifications in Automatic Sprinkler System Layout, Special Hazards Suppression Systems and Inspection and Testing of Water Based Systems.
- Lisa has over 20 years experience in the IT and Training fields and has a Master’s Degree in Computer Science

Live Webinar Presentation:

- Estimated Webinar Time: 60 minutes
- Internet Access and Phone Line Needed